

NOOREVA

AIR ACTIVE 104

User Manual

Diagrammatic Sketch



- ①Indicator light
- ②Type-c interface
- ③Touch area

Specifications

- Product model: AIR ACTIVE 104
- Bluetooth solutions: JL6973
- Bluetooth version:V5.3
- Bluetooth working frequency:2.402GHz-2.480GHz
- Speaker size: 10mm
- Effective distance: 10m
- Earphones battery capacity: 30mAh
- Charging case battery capacity:200mAh
- Playing time:4-5 hours
- Earphone charging time: about 2 hour

Package List

- Bluetooth headset (2PCS)
- Earphone Charging box
- Type-c charging cable
- User's manual
- Gift package
- Earphone caps (2 pairs)



Paring

1: Auto Pairing

Taking the earphones out of the charging case, and then the earphones will automatically turn on, sync together and enter pairing mode.

2: Syncing your earphones..

When earphones do not sync together or enter disconnected state during use.

1): Turn off both earphones and turn back on.

2): If that does not work, placing both earphones back into case, closing the charging case and then open the charging case again.

3: Open up Bluetooth setting on your smart device and scan for AIR ACTIVE 104.

Operation

1: Power on/off .

1.) Take the earphones out of the charging case, automatically turn on;
Put the earphones back to the charging case, automatically turn off;

2.) Long press 3 seconds to turn on.
Long press 5 seconds to turn off.

2: Play/Pause music.

When listening to music.

Quick tap the left/right earphones once to play or pause the music.

3: Previous /Next Song

When listening to music.

Press left earphones 3 times to previous song.

Press right earphones 3 times to next song.

4: Volume +/-

Double Tap left earphones twice to decrease the volume.

Double Tap right earphones twice to increase the volume.

5: Answer/Hang up

When there is an incoming call.

Tap left or right earphones once to answer the call.

Tap left or right earphones again to end the call.

6: Reject

When there is an incoming call.

Long press left or right earphones for 2 seconds to reject the call.

7: Voice assistant

Long press left or right earphones 3 seconds to activate voice assistant.